



## **Method Statement for the off loading of Bamtec**

- 1. Once the carpets are chocked and ready for lifting from the wagon, there should be no other personnel on the bed of the trailer, and everyone involved with the lift must be clear before the crane snatches the load.**
- 2. Access to and from the bed of the vehicle should only be undertaken by the use of a ladder.**
- 3. When clear of the wagon carpets should be placed on timbers for ease of movement on to the deck.**
- 4. Only use tested slings / chains to unload/ place materials**
- 5. Qualified banksmen only should undertake supervise lifts and discharges.**